

Sealing with SEMCO Teak Sealer

- Let furniture weather naturally outside for approximately 2-3 weeks.
- Wash furniture with a mild, soapy warm water & scotch-brite pad, rinse well. Do not use a pressure washer.
- Let furniture dry – minimum 1 day.
- Protect the area you are working around and always wear gloves. Wear goggles if you are spraying the SEMCO.
- For best results, apply sealer in the shade or on a overcast/cloudy day.
- Apply with a terry cloth rag, paintbrush or spray bottle. Wipe any excess sealer to prevent blotching.
- Apply two coats back to back. Initial sealing is always two coats. Recoating once every year is usually sufficient, however two coats may be required depending on your sun exposure.
- If you get the sealer on the Batyline mesh – remove with warm soapy water prior to the sealer drying.
- The sealer is dry to the touch within 30-60 minutes.
- If you choose to clear coat the table top with the SEMCO clear coat; after the initial sealing is complete, apply two thin coats 8 hours apart. **DO NOT APPLY** if rain is expected.